



**FIG. 1**  
(Prior Art)


1/12




**FIG. 2A**



**FIG. 2B**



**FIG. 3A**



**FIG. 3B**

FIG. 1 2 3 4 5 6 7 8 9 \* 0 #

FIG. 3C




FIG. 3C

2/12




FIG. 3D




FIG. 3E




FIG. 4A





FIG. 4B



This diagram illustrates a method for inputting information by touching a character or symbol. It shows three vertical columns representing different input options: A, B, and C.

- Top Section:** Three square boxes are shown, each containing a character or symbol. The first box contains 'A' (labeled 56), the second contains 'B' (labeled 57), and the third contains 'C' (labeled 30i). These boxes are part of a larger set labeled 30j. Other labels include 34, 35a, 36a, 37a, and 58.
- Middle Section:** Below the top section, there is a horizontal line labeled 55. Below this line, the text "USER ACTION" is written. Underneath "USER ACTION", there are three downward-pointing arrows labeled A, B, and C, indicating the user's selection.
- Bottom Section:** Below the arrows, there are three rectangular boxes labeled 35a, 36a, and 37a. These boxes are connected to the top section by dashed lines. At the bottom, there is a horizontal line labeled 28b. Below this line, there are three curved lines labeled 44, 44, and 52, which represent the physical components of the device.

**FIG. 4E**

4/12




FIG. 5A




FIG. 5B

6/12




FIG. 5C




FIG. 5D

		DISPLAY			
Button	Mode of operation	SHIFT Position	Action A	Action B	Action C
1	NUMERIC/SHIFT OFF		1	1	1
2	NUMERIC/SHIFT OFF		2	2	2
3	NUMERIC/SHIFT OFF		3	3	3
4	NUMERIC/SHIFT OFF		4	4	4
5	NUMERIC/SHIFT OFF		5	5	5
6	NUMERIC/SHIFT OFF		6	6	6
7	NUMERIC/SHIFT OFF		7	7	7
8	NUMERIC/SHIFT OFF		8	8	8
9	NUMERIC/SHIFT OFF		9	9	9
*	NUMERIC/SHIFT OFF		*	*	SHIFT ON
0	NUMERIC/SHIFT OFF		0	0	0
#	NUMERIC/SHIFT OFF		#	#	#
1	ALPHA/SHIFT ON	SHIFT	+	-	/
2	ALPHA/SHIFT ON	SHIFT	A	B	C
3	ALPHA/SHIFT ON	SHIFT	D	E	F
4	ALPHA/SHIFT ON	SHIFT	G	H	I
5	ALPHA/SHIFT ON	SHIFT	J	K	L
6	ALPHA/SHIFT ON	SHIFT	M	N	O
7	ALPHA/SHIFT ON	SHIFT	P	R	S
8	ALPHA/SHIFT ON	SHIFT	T	U	V
9	ALPHA/SHIFT ON	SHIFT	W	X	Y
*	ALPHA/SHIFT ON	SHIFT	Q	*	SHIFT OFF
0	ALPHA/SHIFT ON	SHIFT	\	@	SPACE
#	ALPHA/SHIFT ON	SHIFT	Z	#	•

Fig. 6A



		DISPLAY			
Button	Mode of operation	SHIFT Position	Action A	Action B	Action C
1	NUMERIC/SHIFT OFF		1	1	1
2	NUMERIC/SHIFT OFF		2	2	2
3	NUMERIC/SHIFT OFF		3	3	3
4	NUMERIC/SHIFT OFF		4	4	4
5	NUMERIC/SHIFT OFF		5	5	5
6	NUMERIC/SHIFT OFF		6	6	6
7	NUMERIC/SHIFT OFF		7	7	7
8	NUMERIC/SHIFT OFF		8	8	8
9	NUMERIC/SHIFT OFF		9	9	9
*	NUMERIC/SHIFT OFF		*	*	*
0	NUMERIC/SHIFT OFF		0	0	0
#	NUMERIC/SHIFT OFF		#	#	#
1	ALPHA/SHIFT ON	SHIFT	+	-	/
2	ALPHA/SHIFT ON	SHIFT	A	B	C
3	ALPHA/SHIFT ON	SHIFT	D	E	F
4	ALPHA/SHIFT ON	SHIFT	G	H	I
5	ALPHA/SHIFT ON	SHIFT	J	K	L
6	ALPHA/SHIFT ON	SHIFT	M	N	O
7	ALPHA/SHIFT ON	SHIFT	P	R	S
8	ALPHA/SHIFT ON	SHIFT	T	U	V
9	ALPHA/SHIFT ON	SHIFT	W	X	Y
*	ALPHA/SHIFT ON	SHIFT	Q	(	*
0	ALPHA/SHIFT ON	SHIFT	\	@	SPACE
#	ALPHA/SHIFT ON	SHIFT	Z	)	#

Fig. 6B

10/12

KEY PRESSED		INPUT RECEIVED	
		COLUMN	ROW
1	LEFT	1	1
	RIGHT	2	1
2	LEFT	3	1
	RIGHT	4	1
3	LEFT	5	1
	RIGHT	6	1
4	LEFT	1	2
	RIGHT	2	2
5	LEFT	3	2
	RIGHT	4	2
6	LEFT	5	2
	RIGHT	6	2
7	LEFT	1	3
	RIGHT	2	3
8	LEFT	3	3
	RIGHT	4	3
9	LEFT	5	3
	RIGHT	6	3
*	LEFT	1	4
	RIGHT	2	4
0	LEFT	3	4
	RIGHT	4	4
#	LEFT	5	4
	RIGHT	6	4

Fig. 7

FOOTNOTES

11/12

KEY PRESSED		INPUT RECEIVED	
		COLUMN	ROW
1	LEFT	1	1
	CENTER	2	1
	RIGHT	3	1
2	LEFT	4	1
	CENTER	5	1
	RIGHT	6	1
3	LEFT	7	1
	CENTER	8	1
	RIGHT	9	1
4	LEFT	1	2
	CENTER	2	2
	RIGHT	3	2
5	LEFT	4	2
	CENTER	5	2
	RIGHT	6	2
6	LEFT	7	2
	CENTER	8	2
	RIGHT	9	2
7	LEFT	1	3
	CENTER	2	3
	RIGHT	3	3
8	LEFT	4	3
	CENTER	5	3
	RIGHT	6	3
9	LEFT	7	3
	CENTER	8	3
	RIGHT	9	3
*	LEFT	1	4
	CENTER	2	4
	RIGHT	3	4
0	LEFT	4	4
	CENTER	5	4
	RIGHT	6	4
#	LEFT	7	4
	CENTER	8	4
	RIGHT	9	4

Fig. 8

FOOT 0347000

12/12




Fig. 9